


OPTIONAL: USER INTERFACE BOARD + WIRING (QUELLE INPUT)

NOT INCLUDED IN THE WIRING HARNESS  
ONLY IN VERSION WITH LCD

# (HIGH) ENV06 DRYER



Junction box +  
Anti-interference filter