



29




OVEN SWITCH

	0	30	270	300	330
POS.	0	30	270	300	330
4-P2		■			
3-P1			■		
1-P1				■	
2-P1			■	■	
5-P3		■			■

HOB SWITCH

THE SEVEN POSITIONS OF THE SWITCH ARE EQUIDISTANT DISTRIBUTED



	0	6	5	4	3	2	1
POS.	0	6	5	4	3	2	1
4 - P2		■	■		■	■	
3 - P2				■			■
3 - P1					■		
1 - P1						■	
2 - P1			■	■			
5 - P3		■					■