



OVEN SWITCH

	0	90-	270	300
POS.	0	30	240	270
4 - P2				
3 - P1				
1 - P1				
2 - P1				
5 - P3				

HOB SWITCH

THE SEVEN POSITIONS OF THE SWITCH ARE EQUIDISTANT DISTRIBUTED

POS	0	6	5	4	3	2	1
4 - P2							
3 - P2							
3 - P1							
1 - P1							
2 - P1							
5 - P3							

