


DESCRIPTION OF THE APPLIANCE


Control panel

Model : ZCC 5069



1. Oven thermostat pilot light
2. Oven function control knob
3. Front left burner control knob
4. Back left burner control knob
5. Back right burner control knob
6. Front right burner control knob
7. Top ignition switch

Hob



1. Front left burner (semi-rapid)
2. Back left burner (semi-rapid)
3. Back right burner (auxiliary)
4. Front right burner (rapid)