


DESCRIPTION OF THE APPLIANCE


Control panel

Model : ZCG 5500



1. Oven light /Turn spit switch
2. Oven /Grill function control knob
3. Front left burner control knob
4. Back left burner control knob
5. Back right burner control knob
6. Front right burner control knob
7. Top/oven ignition switch

Hob



1. Front left burner (rapid)
2. Back left burner (semi-rapid)
3. Back right burner (rapid)
4. Front right burner (auxiliary)

DT000439