



342750760-02



HOB SWITCH (clockwise rotation)  
THE SEVEN POSITIONS OF THE SWITCH  
ARE EQUIDISTANT DISTRIBUTED

POS	0	1	2	3	4	5	6
4 - P2			■	■	■	■	■
3 - P2		■					
3 - P1			■	■			
1 - P1					■	■	
2 - P1							■
5 - P3		■					

46. 27266. 620



OVEN SWITCH

POS.	0	72	144	216	288
4-P2		■	■	■	■
3-P1			■	■	■
1-P1				■	■
2-P1					■
5-P3		■			

46. 25866. 808