



OVEN SWITCH 46.25866.808

POS.	0	72	144	216	288
4-P2		▬		▬	
3-P1					▬
1-P1					▬
2-P1		▬		▬	
5-P3					▬