


OVEN SWITCH

POS.	0	30	90	270	300
4-P2					
3-P1					
1-P1					
2-P1					
5-P3					

46. 23866. 815



HOB SWITCH (clockwise rotation)
THE SEVEN POSITIONS OF THE SWITCH

ARE EQUIDISTANT DISTRIBUTED

POS	0	1	2	3	4	5	6
4 - P2							
3 - P2							
3 - P1							
1 - P1							
2 - P1							
5 - P3							

46. 27266. 620

