



OVEN SWITCH 42.07000.059

POS.	0	1	2	3	4	5	6
1-P1		■					
2-P2			■				
3-P3				■			
4-P4					■		
5-P5						■	
6-P6			■				
7-P7							■
8-P8		■					

