



HOB SWITCH (clockwise rotation)

POS	0	1	2	3	4	5	6
4 - P2		■					■
3 - P2			■				■
3 - P1				■			■
1 - P1		■					■
2 - P1				■			■
5 - P3					■		■

46.27266.620

OVEN SWITCH

POS.	A	0	72	144	216	288
4-P2			■		■	
3-P1				■		■
1-P1		■				■
2-P1				■		■
5-P3					■	■

46.25866.808

