



OVEN SWITCH 42.07001.005

	0	1	2	3	4	5	6
POS.							
1-P1		—	—	—	—	—	—
2-P2			—	—		—	—
3-P3		—		—			
4-P4		—	—				
5-P5					—	—	
6-P6						—	—
7-P7		—	—	—	—	—	—
8-P8		—	—	—	—	—	—