



230/400V

29




- 37** 145 N 1000W **4**
- 38** 180 R 2000W **3**
- 38** 145 R 1500W **2**
- 37** 180 N 1500W **1**

20



342750868



HOB SWITCH (clockwise rotation)


POS	0	1	2	3	4	5	6
4 - P2							
3 - P2							
3 - P1							
1 - P1							
2 - P1							
5 - P3							

46. 27266. 620

OVEN SWITCH

POS.	0	1	2	3	4	5	6	7
1-P1								
2-P2								
3-P3								
4-P4								
5-P5								
6-P6								
7-P7								
8-P8								

42. 08000. 033



	0	120°
1-2		
1-2		

MM7-527