



HOB SWITCH (clockwise rotation)

POS	0	1	2	3	4	5	6
4 - P2							
3 - P2							
3 - P1							
1 - P1							
2 - P1							
5 - P3							

46.27266.620

OVEN SWITCH

POS.	<div style="display: flex; gap: 10px;"> <span> 1</span> <span> 2</span> <span> 3</span> <span> 4</span> <span> 5</span> <span> 6</span> </div>						
	0	1	2	3	4	5	6
1-P1							
2-P2							
3-P3							
4-P4							
5-P5							
6-P6							
7-P7							
8-P8							
1-P1							
2-P2							

42.07100.008

