


HOB SWITCH (clockwise rotation)

POS	0	1	2	3	4	5	6
4 - P2							
3 - P2							
3 - P1							
1 - P1							
2 - P1							
5 - P3							

46.27266.620

PNC 943 265 242



PNC 943 265 247

OVEN SWITCH

POS.	0	1	2	3	4	5	6
4-P2							
3-P1							
1-P1							
2-P1							
5-P3							

46.27866.501