



HOB SWITCH (clockwise rotation)

POS	0	1	2	3	4	5	6
4 - P2							
3 - P2							
3 - P1							
1 - P1							
2 - P1							
5 - P3							

46.27266.620

OVEN SWITCH

42.09000.026

POS.	0	1	2	3	4	5	6	7	8
1-P1									
2-P2									
3-P3									
4-P4									
5-P5									
6-P6									
7-P7									
8-P8									

