



-
- 4
3
2
1



HOB SWITCH (clockwise rotation)

POS	0	1	2	3	4	5	6
4 - P2			▬	▬		▬	▬
3 - P2		▬			▬		
3 - P1			▬				
1 - P1		▬					▬
2 - P1			▬				
5 - P3		▬	▬	▬			

46.27266.620

OVEN SWITCH

POS.	0	60	120	180	240	300
4-P2		▬	▬	▬	▬	▬
3-P1			▬			
1-P1		▬				
2-P1		▬				
5-P3					▬	▬

46.23866.814