

HOB SWITCH (clockwise rotation)


POS	0	1	2	3	4	5	6
4 - P2							
3 - P2							
3 - P1							
1 - P1							
2 - P1							
5 - P3							

357033202 (46.27266.620)

OVEN SWITCH

POS.	0	72	144	216	288
1-P1					
2-P2					
3-P3					
4-P4					
5-P5					
6-P6					
7-P7					
8-P8					

42.05001.001



342 7621 01