



OVEN SWITCH

POS.	A	0	72	144	216	288
4-P2			■		■	
3-P1						■
1-P1						■
2-P1			■	■		
5-P3			■	■	■	■