



74

342 7666 01



OVEN SWITCH

POS.	0	OVEN SWITCH				
		⊘	≡	≡	≡	
		30	60 ÷ 240	270	300	330
4-P2						
3-P1						
1-P1						
2-P1						
5-P3						

46.23866.862