



OVEN SWITCH 42.07001.005

	0	1	2	3	4	5	6
POS.							
1-P1		—					
2-P2			—				
3-P3				—			
4-P4					—		
5-P5						—	
6-P6							—
7-P7							
8-P8							