



OVEN SWITCH

POS.	0	1	2	3	4	5	6
1 - P1							
2 - P2							
3 - P3							
4 - P4							
5 - P5							
6 - P6							
7 - P7							
8 - P8							

DOUBLE ENERGY REGULATOR	
POSITION	0
S	S
P2	4
P1	3
4	4A

ENERGY REGULATOR	
POSITION	0
S	S
P2	4
P4	3