



OVEN SWITCH
3570439 (46.25866.808)

POS.	0	72	144	216	288
4-P2		■			
3-P2		■	■		
3-P1				■	
1-P1					■
2-P1		■			
5-P3				■	■

HOB SWITCH
46.27266.500

POS.	0	6	5	4	2	1
4-P2		■				
3-P2		■	■			
3-P1				■		
1-P1					■	
2-P1		■				
5-P3				■	■	