



OVEN SWITCH 3427571 (42.09100.003)

POS	0	1	2	3	4	5	6	7	8
1-P1									
2-P2									
3-P3									
4-P4									
5-P5									
6-P6									
7-P7									
8-P8									
1-P1									
2-P2									

