



342770729 342770736

OVEN SWITCH

POS.	0	1	2	3	4	5	6
1-P1		■	■	■	■	■	■
2-P2			■	■	■	■	■
3-P3		■		■	■	■	■
4-P4		■	■		■	■	■
5-P5			■	■		■	■
6-P6		■	■	■	■		■
7-P7		■	■	■	■	■	■
8-P8		■	■	■	■	■	■

3570285 (42.07001.005)

