



342 1340 01 (46.26866.521)

OVEN SWITCH							
POS.	0						
4-P2							
3-P1							
1-P1							
2-P1							
5-P3							

