



OVEN SWITCH

POS.	0	1	2	3	4	5	6
1-P1							
2-P2							
3-P3							
4-P4							
5-P5							
6-P6							
7-P7							
8-P8							

3570285 (42.07001.005)