


342770721 342770736

OVEN SWITCH

0-0	0	1	2	3	4	5	6	7	8
1-P1	0	1	1	1	1	1	1	1	1
2-P2	0	1	1	1	1	1	1	1	1
3-P3	0	1	1	1	1	1	1	1	1
4-P4	0	1	1	1	1	1	1	1	1
5-P5	0	1	1	1	1	1	1	1	1
6-P6	0	1	1	1	1	1	1	1	1
7-P7	0	1	1	1	1	1	1	1	1
8-P8	0	1	1	1	1	1	1	1	1



- Coduri cablaj:
- 3421389
  - 342134603
  - 342770736
  - 342770729
  - 342770721
  - 342770735-pt.gril rabatabil
  - 3421459