


OVEN SWITCH

POS.	0	60	120	180	240	300
4-P2						
3-P1						
1-P1						
2-P1						
5-P3						



74