



OVEN SWITCH

POS.	0	1	2	3	4	5	6	7	8	9
1-P1										
2-P2										
3-P3										
4-P4										
5-P5										
6-P6										
7-P7										
8-P8										

