



ENERGY REGULATOR

POSITION	0	1	max
S	→ S		
P2	→ 4		
P1	→ 1		

DOUBLE ENERGY REGULATOR

POSITION	0	1	3max
S	→ S		
P2	→ 4		
P1	→ 1		
4	→ 4A		

OVEN SWITCH

342152701
42.00900.067

	☀	▬	▬	⚡	⚡	⚡	⚡	⚡	⚡	
POS.	0	1	2	3	4	5	6	7	8	9
1-P1		▬	▬	▬	▬	▬	▬	▬	▬	▬
2-P2			▬	▬	▬	▬	▬	▬	▬	▬
3-P3				▬	▬	▬	▬	▬	▬	▬
4-P4					▬	▬	▬	▬	▬	▬
5-P5						▬	▬	▬	▬	▬
6-P6							▬	▬	▬	▬
7-P7								▬	▬	▬
8-P8									▬	▬

OVEN SWITCH

342757621
42.00000.045

	☀	▬	▬	⚡	⚡	⚡	⚡	⚡	⚡	
POS.	0	1	2	3	4	5	6	7	8	9
1-P1		▬	▬	▬	▬	▬	▬	▬	▬	▬
2-P2			▬	▬	▬	▬	▬	▬	▬	▬
3-P3				▬	▬	▬	▬	▬	▬	▬
4-P4					▬	▬	▬	▬	▬	▬
5-P5						▬	▬	▬	▬	▬
6-P6							▬	▬	▬	▬
7-P7								▬	▬	▬
8-P8									▬	▬