



OVEN SWITCH
3570439 (46.25866.808)

POS.	0	72	144	216	288
4-P2					
3-P1					
1-P1					
2-P1					
5-P3					

HOB SWITCH
46.27266.500

POS	0	6	5	4	3	2	1
4-P2							
3-P2							
3-P1							
1-P1							
2-P1							
5-P3							