



OVEN SWITCH

| POS. | 0 | 60 | 120 | 180 | 240 | 300 |
|------|---|----|-----|-----|-----|-----|
| 4-P2 |   | ■  | ■   | ■   | ■   | ■   |
| 3-P1 |   |    | ■   | ■   | ■   | ■   |
| 1-P1 |   | ■  | ■   | ■   | ■   | ■   |
| 2-P1 |   | ■  | ■   | ■   | ■   | ■   |
| 5-P3 |   |    |     | ■   | ■   | ■   |

3570069 (46.23866, 814)

