



LEFT FRONT PANEL

Hob Svs.

OVEN SWITCH

	0	1	2	3	4	5	6	ETC
POS.								
1-P1		■	■	■	■	■	■	■
2-P2			■	■	■	■	■	■
3-P3				■	■	■	■	■
4-P4					■	■	■	■
5-P5						■	■	■
6-P6							■	■
7-P7								■
8-P8								■

342 7585 21(4208000.033)

DOUBLE ENERGY REGULATOR

POSITION	0	1	3max
S → S		■	■
P2 → 4			■
P1 → 1			■
4 → 4A			■

ENERGY REGULATOR

POSITION	0	1	max
S → S		■	■
P2 → 4			■
P1 → 1			■