



OVEN SWITCH

POS.	0	1	2	3	4	5	6
1-P1							
2-P2							
3-P3							
4-P4							
5-P5							
6-P6							
7-P7							
8-P8							

342 7585 21(4208000.033)

HOB SWITCH

POS	0	6	5	4	3	2	1
4-P2							
3-P2							
3-P1							
1-P1							
2-P1							
5-P3							

387 2073 00(46.27266.500)