

OVEN SWITCH


POS	0	1	2	3	4	5	6	7	8
1-P1									
2-P2									
3-P3									
4-P4									
5-P5									
6-P6									
7-P7									
8-P8									
1-P1									
2-P2									

342757121 (42.09100.003)

OVEN SWITCH

POS	0	1	2	3	4	5	6	7	8
1-P1									
2-P2									
3-P3									
4-P4									
5-P5									
6-P6									
7-P7									
8-P8									
1-P1									
2-P2									

342152601 (42.09100.009)



HOB SWITCH

POS	0	6	5	4	3	2	1
4-P2							
3-P2							
3-P1							
1-P1							
2-P1							
5-P3							

387 2073 00(46.27266.500)