



OVEN SWITCH

POS.	0	1	2	3	4	5	6
1-P1		●					
2-P2			■				
3-P3				■			
4-P4					■		
5-P5						■	
6-P6							■
7-P7							
8-P8							
1-P1		■					
2-P2			■				

HOB SWITCH

POS	0	6	5	4	3	2	1
4-P2							
3-P2							
3-P1							
1-P1							
2-P1							
5-P3							