



OVEN SWITCH

POS.	0	60	120	180	240	300
4-P2						
3-P1						
1-P1						
2-P1						
5-P3						

342 1340 01 (46.26866.521)

OVEN SWITCH

POS.	0	60	120	180	240	300
4-P2						
3-P1						
1-P1						
2-P1						
5-P3						

342153201 (46.26866.525)

HOB SWITCH

POS.	0	5	4	3	2	1
4-P2						
3-P1						
2-P1						
1-P1						
5-P3						

387 2073 00146.27266.500

342140306