



OVEN SWITCH

POS.	0	72	144	216	288
4-P2					
3-P1					
1-P1					
2-P1					
5-P3					

HOB SWITCH

POS.	0	6	5	4	3	2	1
4-P2							
3-P2							
3-P1							
1-P1							
2-P1							
5-P3							

3570439 (46.25866.808)

387 2073 00(46.27266.500)

342143105