



OVEN SWITCH	0	60	120	180	240	300
4-P2						
3-P1						
1-P1						
2-P1						
5-P3						

HOB SWITCH	0	6	5	4	3	2	1
4-P2							
3-P1							
1-P1							
2-P1							
5-P3							

342153201(46.23866.525)

387 2073 00146.27266.500)