



OVEN SWITCH

POS.	0	72	144	216	288
4-P2		■		■	
3-P1			■		■
1-P1		■		■	
2-P1			■		■
5-P3		■		■	

HOB SWITCH

POS.	0	6	5	4	3	2	1
4-P2		■		■		■	
3-P1			■		■		■
1-P1		■		■		■	
2-P1			■		■		■
5-P3		■		■		■	

3570439 (46.25866.808)

387 2073 00(46.27266.500)