



Nota: Cutia de conex. este obligatorie pe Ls. Th. si Ls. Hob!

OVEN SWITCH

POS.	0	60	120	180	240	300
4-P2		■	■	■	■	■
3-P1			■	■	■	
1-P1		■		■		
2-P1		■			■	
5-P3					■	■

3570069 (46.23866.814)

HOB SWITCH

	0	6	5	4	3	2	1
POS.	0	6	5	4	3	2	1
4-P2		■		■		■	
3-P2			■		■		
3-P1				■		■	
1-P1		■					
2-P1		■					
5-P3						■	■

387 2073 00(46.27266.500)

342152104