



OVEN SWITCH

POS.	0	72	144	216	288
4-P2		■		■	
3-P1					■
1-P1					
2-P1		■	■	■	
5-P3					■

3570439 (46.25866.808)

POS	0	6	5	4	2	1
4-P2		■		■	■	
3-P2						■
3-P1						
1-P1		■	■	■	■	
2-P1						■
5-P3						■

387 2073 00(46.27266.500)

342145302