



OVEN SWITCH

POS.	0	60	120	180	240	300
4-P2		■	■	■	■	■
4-P2		■	■	■	■	■
3-P1						
1-P1		■				
2-P1						■
5-P3						

342153201 (46.26866.525)

HOB SWITCH

POS	0	6	5	4	3	2	1
4-P2		■	■				
3-P2							
3-P1							
1-P1		■					
2-P1							
5-P3							

387 2073 00(46.27266.500)