



OVEN SWITCH  
3570439 (46.25866.808)

POS.	0	72	144	216	288
4-P2		■			
3-P1			■		
1-P1				■	
2-P1		■			
5-P3				■	

HOB SWITCH  
46.27266.500

POS	0	6	5	4	3	2	1
4-P2		■					
3-P2			■				
3-P1				■			
1-P1					■		
2-P1		■					
5-P3						■	