



OVEN SWITCH

POS	1	2	3	4	5	6	7	8
1-P1								
2-P2								
3-P3								
4-P4								
5-P5								
6-P6								
7-P7								
8-P8								
1-P1								
2-P2								

342757121 (42.09100.003)

OVEN SWITCH

POS	1	2	3	4	5	6	7	8
1-P1								
2-P2								
3-P3								
4-P4								
5-P5								
6-P6								
7-P7								
8-P8								
1-P1								
2-P2								

342152601 (42.09100.009)

