



- (T1) THERMOSTAT FREEZER
- (T2) THERMOSTAT FRIDGE
- (S1) LAMP SWITCH
- (S2) SUPER SWITCH
- (L1) LAMP  
(placed in top panel or fridge department.)
- (L2) SIGNAL LAMP FRIDGE
- (L3) SIGNAL LAMP ALARM
- (L4) SIGNAL LAMP FREEZER
- (L5) SUPER LAMP
- (C) RUN CAPACITOR
- (J) MOTORPROTECTOR
- (H) STARTING DEVICE
- (F) FLEXIBLE CORD
- (E) EARTH CABINET
- (P) PRINTED CIRCUIT

S20576630