



- | | | |
|--|------------------------|---------------------|
| (B) ALARM BUZZER | (L5) SIGNAL LAMP SUPER | SIGNALLAMPE SUPER |
| THERMOSTAT GEFRIER (T1) THERMOSTAT FREEZER | (C) RUNNING CAPACITOR | BETRIEBSKONDENSATOR |
| THERMOSTAT KÜHL (T2) THERMOSTAT FRIDGE | (R) ALARM RESET KEY | |
| SCHALTER SUPER (S) SUPER SWITCH | (J) MOTORPROTECTOR | MOTORSCHUTZSCHALTER |
| LAMPE (L1) LAMP | (H) STARTING DEVICE | ANLAUFVORRICHTUNG |
| SIGNALLAMPE KÜHL (L2) SIGNAL LAMP FRIDGE | (F) FLEXIBLE CORD | NETZKABEL |
| SIGNALLAMPE ALARM (L3) SIGNAL LAMP ALARM | (E) EARTH CABINET | ERDE |
| SIGNALLAMPE GEFRIER (L4) SIGNAL LAMP FREEZER | (P) PRINTED CIRCUIT | LEITERPLATTE |