

Top-ten spare parts caravan

Spare part number	Models
Thermostat, electric	
292 6528-10/6, 1400mm	all caravan refrigerators except Luxembourg KTL
Thermostat, gas	
292 3755-02/5, 1400mm	all caravan refrigerators except Luxembourg KTL
295 2168-10/8 stop valve with gas thermostat	consist of 292 7657-10/2, stop valve and 292 3755-02/5, gas thermostat
Compact mountings gas/electric	
241 2190-20/5, 1500mm	RM 6270/71/90/91;6360/61;6400/01;7270/90;7360;7400 RM 7540/50;7650;7850;RM/S/L 8XX0;RGE 2000;T 105GE
Selector switch gas/electric	
295 2025-21/7	RM 6270/71/90/91;6360/61;6400/01;7270/90;7360;7400 RM 7540/50;7650;7850;RM/S/L 8XX0;RGE 2000;T 105GE
Heating element	
241 3230-00/0, 230V/105W, bent	RM 200;201;270;2210/50;4180/81;4200/01/03/10/11/12 RM 4213/30/31/32/33;5211;GM 60B;GM 65H
292 3331-30/6, 12V/100W, bent Service heating element	RM 200;201;270;2210/50;4180/81;4200/01/03/10/11/12 RM 4213/30/31/32/33;5211;GM 60B;GM 65H RM 4185/4215/35 (AESII)
292 3331-01/7, 24V/100W, bent	RM 200;201;270;2210/50;4180/81;4200/01/03/10/11/12 RM 4213/30/31/32/33;5211;GM 60B;GM 65H
295 2173-10/8, 230V/105W, bent	RM 4185;4215/35 (AESII)
289 0209-20/4, 235V/125W, bent	RM 275;300;301;400;4240/60/61/62/63/70/71/80/81/90/91 RM 4300/01/70/71;5270/71;5310/30/80 RM 6270/71/90/91;7270/71/90/91;7370/90 RMS 8400/01/05/60/61/65;8500/01/05/50/51/55 RA 4421/22;GE 105;S105 GE;RGE 200;RE 200 RM 4210/11/12/13/30/31/32/33;5211 with cooling unit RM 2202
289 0180-00/9, 235V/125W, bent	RMS 8401/05;RMS 8501/05/51/55 MES4/AES4
292 3420-20/8, 12V/120W, bent Service heating element	RM 275;300;301;400;4240/60/61/62/63/70/71/80/81/90/91 RM 4300/01/70/71;5270/71;6270/71/90/91;7270/71/90/91 RA 4421/22;GE 105;S105 GE;RGE 200;RE 200 RMS 8400/01/05/60/61/65;8500/01/05/50/51/55 RM 4210/11/12/13/30/31/32/33;5211 with cooling unit RM 2202 RM 4215/65/75/85;5215/75;6275/95 (AESII)
292 3420-01/8, 24V/120W, bent	RM 275;300;301;400;4240/60/61/62/63/70/71/80/81/90/91 RM 4300/01/70/71;5270/71;7270/71/90/91 RA 4421/22;GE 105;S105 GE;RGE 200;RE 200 RM 4210/11/12/13/30/31/32/33;5211 with cooling unit RM 2202
295 2174-30/4, 230V/125W, bent	RM 4215/65/75/85;5215/75;6275/95 (AESII)
289 0209-10/5, 235V/135W, bent	RM 4360/61;4400/01;5401;GM 90H;RGE 2100;T115GE RM 8400/01/05;8500/01/05/50/51/55 MES4/AES4

Spare part number	Models
Heating element	
295 1694-30/2, 12V/130W, bent Service heating element	RM 4360/61;4400/01;5401;6360/61;6400/01;7360/61/65 RM 7400/01/05;7540/41/45/50/51/55;GM 90H RM 8400/01/05;8500/01/05/50/51/55 RM 4365;4405;5405;6365;6405 (AESII)
295 1694-01/3, 24V/130W, bent	RM 4360/61;4400/01;5401;GM 90H
295 2170-20/3, 230V/135W, bent	RM 4365;4405;5405;6365;6405 (AESII)
241 3229-31/7, 235V/135W, bent	RM 6360/61;6400/01;7360;7400;7540/50;RGE 2000 RM 8400;8500/50
241 3229-40/8, 235V/135W, bent	RM 7361/65;7401/05;7541/45/51/55
241 3229-41/6, 235V/135W, bent	RM 8401/05;8501/05/51/55
289 0209-00/6, 230V/190W, bent	RM 7601/05/50/51/55;7850/51/55;RML/SL 8500/01/50/51/55 RMD/T 8501/05/51/55; MES/AES + MES4/AES4
241 2968-10/5, 12V/170W, bent	RM 7601/05/50/51/55;7850/51/55;RML 8330 RML 8550/51/55;RMSL 8500/01
289 0170-52/1, 12V/170W, bent	RMD/T 8501/05/51/55;RML 8550/51/55;RMSL 8500/01 MES4/AES4
	the preceding heating elements have a diameter about 9,6mm
292 9491-39/3, 220V/85W, straight	RM 182-185
292 9491-70/8, 220V/75W, straight	RC 160/1600/2000
292 9491-13/8, 12V/75W, straight	RC 160/1600/2000
292 9491-17/9, 24V/75W, straight	RC 160/1600/2000
207 2514-01/7, 230V/65W, straight	RC 1500
Thermocouple	
292 3435-32/1, 1400mm	for caravan fridges up to 103l, except RM 7XX1/5;8XX1/5
293 2333-02/0	for caravan fridges from 103l on, except RM 7XX1/5;8XX1/5
Thermo current breaker	
295 2985-00/6	RM 6XXX;7XX0;RGE 2000;T 105GE
Exhaust pipe, kit	
293 5551-00/8, 195mm	for caravan refrigerators up to 103l
Fan-kit	
241 2985-01/8, Fan-kit	absorption-system (ask Dometic sales department)
241 2906-20/4, Thermostat for Fan-kit	absorption-system
Door security	
292 6260-01/5	old version (old refrigerators RM XXX)
295 2700-00/9	door security 2-buttons (RM 4XXX;5XXX)
241 2345-60/1	door security rotatable right and left (RM 6XXX)
241 2345-70/0	door security rotatable right and left, metal (RM 6XXX)
241 2757-30/0, (241 3272-00/2, Slider)	door security on the door RM 7270/71/75/90/91/95;7360 RM 7361/65/90/91/95;7400/01/05
241 2757-60/7, (241 2883-90/8, Slider)	RM 7550/51/55;7600/01/05
241 2757-80/5, (289 0119-00/7, Slider)	RM 7650/51/55;7850/51/55
Piezo lighter / Battery igniter	
292 3024-10/9	for control retainer bracket, steel (red)
292 3024-61/2	for control retainer bracket, plastic (black)
292 3024-81/0	battery igniter
Reigniter	
295 1654-20/7, reigniter	12V for caravan fridges up to 103l, except RM 7XX1/5;8XX1/5
293 5605-10/1, cover	12V for caravan fridges up to 103l, except RM 7XX1/5;8XX1/5
241 2789-30/3, ignition unit	RM 7XX1/5;RM/S/L 8XX1/5
Gasregulator / Safety pilot	
210 6030-10/5 magnetic coil	for safety pilot

Spare part number	Models
Gasregulator / Safety pilot	
292 7657-20/1 stop valve	RM 301;400;4212/13/33/40/62/63/70/71/80/81/90/91 RM 4300/01/60/61/70/71;4400/01;5211;5270/71;5401 GM 60H;GM 90H;G 105;GE 105;NK 105;RA 4420/21 RG 200;RGE 200
295 2168-10/8 stop valve with gas thermostat	consist of 292 7657-10/2, stop valve and 292 3755-02/5, gas thermostat
241 2798-31/2 gas valve, GV100	RM 7XX1/5;RM/S/L 8XX1/5
Switch	
292 6274-10/7	supply voltage, green
292 6275-20/3	switch for reigniter, orange
292 6273-50/5	12V/24V-voltage, red
Ignition plug	
295 1105-71/3	ignition plug with cable for reigniter and AES
292 3626-00/2	ignition plug for piezo igniter
Analogue unit	
289 0189-00/0	RM/D/DT/L/S/SL 8xxx MES4/AES4
MES (Manual energy selection)	
241 2771-11/1, power module	RM 7XX1
241 3490-00/0, power module	RM/S/L 8XX1
241 2784-30/4, shaft, selector switch, light grey	RM 7XX1
241 2785-10/3, shaft, temperature, yellow	RM 7XX1/5
AES (Automatic energy selection)	
407 1329-66/0, power module, AESII	caravan fridges, except RM 7365;7405;7545/55;7605/55 RM 7855
241 2771-20/2, power module, AESIII	RM 7365;7405;7545/55;7605/55;7855
241 3490-12/5, power module, AES	RM/S/L 8XX5
241 2784-20/5, shaft, selector switch, beige	RM 7XX5
241 2785-10/3, shaft, temperature, yellow	RM 7XX1/5
295 1956-20/6	thermocurrent adapter
295 2072-00/3	temperature probe
295 2248-81/9	temperature probe RM/D/DT/L/S/SL 8xx1/5 MES4/AES4
295 2073-30/8	display module, black
Holder for bracket	
292 6011-02/0	RM 301;6270/71/75/90/91/95;6360/61/65;6400/01/05 RM 7270/71/75/90/91/95;7360/61/65;7400/01/05 RGE 2000
Holder for grating	
241 2082-00/6	RM 6270/71/75/90/91/95;6360/61/65;6400/01/05;7270/71 RM 7275/90/91/95;7360/61/65;7400/01/05;7540/41/45 RM 7550/51/55;7650/51/55;7850/51/55;RGE 2000
Others	
241 2865-00/4	Kit, hinge for fullsize freezer door
241 2423-90/3	Gas connection pipe for change RM 4XXX;6XXX into RM 7XXX
295 2461-40/4	Kit, nuts and cuppling tube fitting for gas connection pipe
292 6265-40/2	adjustable hinge pin
292 6265-50/1	Kit, adjustable hinge pin
241 2125-00/3	hinge for evaporator flap (RM 6XXX;7XXX)
241 2125-01/1	hinge for evaporator flap (RM/S 8XXX)
241 2125-11/0	hinge for evaporator flap (RML 8XXX)
241 3327-20/2	Slider for freezer compartment (RM/S/L 8XXX)
407 1425-38/5	thermal mastic, cartridge, 300ml
151 404-00/1	Brush for cleaning the exhaust pipe
295 1766-01/9 (295 1766-99/3, 50 pieces)	lock for air vent grid, white
295 1766-31/6 (295 1766-89/4, 50 pieces)	locking slider for air vent grid, white

Spare part number	Models
Gasburner	
292 3430-52/0 Service burner without jet	for caravan fridges up to 103l, except RM 7XX1/5;8XX1/5
241 2802-83/3 Service burner without jet	RM 7XX1/5;RM/S/L 8XX1/5
292 2033-04/4 jet	KZ 45
292 2033-05/1 jet	KZ 46
292 2033-06/9 jet	KZ 43
292 2033-07/7 jet	KZ 12
292 2033-10/1 jet	KZ 16
Door security / Lighting	
289 0127-11/7	On the door, mechanical lock RM/S 84xx;RMD/T 85xx;RML 855x;RMSL 80xx
241 2126-30/8	On the door, mechanical lock RM/S 85xx
289 0371-01/2	On the housing with lighting, mechanical lock, left hang RM/D/DT/L/S/SL 8xxx
289 0371-11/1	On the housing with lighting, mechanical lock, right hang RM/D/DT/L/S/SL 8xxx
Lighting	
295 1641-42/8 (LED)	RM 4185;4210/11/12/13/15/30/31/32/33/35/60/61/62/63/65 RM 70/71/75/80/81/85/90/91;4300/01/60/61/65;4400/01 RM 4405;5211/15/70/71/75;5400/01/05;6270/71/75/90/91/95 RM 6360/61/65;6400/01/05;7270/71/90/91;7360/61 RM 7400/01;7540/41/45/50/51/55; RM/T 7601/05/50/51/55 RM/T 7850/51/55
295 1380-00/1 (sensor)	RM 4210/11/12/13/30/31/32/33/60/61/62/63/70/71/80/81 RM 4290/91;4300/01/60/61;4400/01;5211/70/71 RM 5400/01;6270/71/90/91;6360/61;6400/01;7270/90 RM 7360;7400;7540/50
295 1380-30/8 (sensor)	RM 4185;4215/35/65/75/85;4365;4405;5215/75;5405 RM 6275/95;6365;6405;7271/91;7361;7401
295 1380-50/6 (sensor)	RM 7541/45/51/55
295 1381-00/9 (sensor)	RM/T 7600/01/05/50/51/55;7850/51/55