

Service-Bulletin

Washing machines

599 530 218 EN

Toploader Clip for drain pump broken

Cause: One of the clips in the socket for fixing the drain pump is broken.

Measure: Fix the drain pump to the socket with an additional screw (No. 602019001/0).

Washer without water protection system:



Screw

Clip



Washer with water protection system:



Screw

