
Appliances with smart control electronics - Calibration

The oven must be calibrated first before the "Auto Cooking" function can be used. Calibration takes approx. 4 hours.

Calibration is not required if the oven is used only for regular cooking (without the "Auto Cooking" function).

Please note the following calibration information:

- **Calibration must be carried out a room temperature below 35°C.**
- Install the oven at its final location before commencing calibration.
- **Establish a permanent connection to the mains power supply before commencing calibration.**
- Remove the grease filter before calibrating the oven.
- If the baking grilles or racks available as optional accessories are attached later, the appliance must be recalibrated with this equipment installed.
- If the installation location, mains power connection, or any of the other listed points is changed, the oven must always be recalibrated to ensure optimal functionality of the AUTO COOKING function.

The calibration function is in the "Settings," "Calibration" menu.

The appliance is ready for operation after calibration is completed and as soon as the oven has cooled down.